

VapeKing Starter Kit Instructions

(VK Discovery, VK Basics, VK Premium)

Charging your VapeKing Batteries

Your VapeKing batteries are rechargeable and will need to be recharged once empty by using the included eGO USB Charger.

1. Connect your VapeKing Battery to the USB Charger by screwing it into the connector on the USB Charger. The USB Charger can be connected to an AC Adapter which is supplied in your kit or straight into a PC USB socket.



2. The light on the charger will turn red as shown above indicating that the battery is now being charged.

3. Once the battery is fully charged, the light on the charger will turn green as shown below. Simply unscrew the battery from the charger as it is now ready for use.



Five Click Protection

Your VapeKing Batteries have a 5 click protection feature which allows you to turn on/off the battery so it does not power on. This is useful if you like to leave the battery in your pocket and stops the battery turning on by accident.

Pressing the button on the battery 5 times within 3 seconds will lock/unlock the battery. Sometimes the battery will ship in the lock state, so you may need to press the button 5 times to unlock it.

The button will flash when you successfully lock/unlock the battery.

Filling your Clearomizers

Your clearomizer, or atomizing device, is what carries the liquid that will be vapourized. Below are the instructions on refilling your clearomizer.

1. Unscrew the base of the clearomizer to reveal the filling chamber.



2. Using a Syringe or a dropper bottle, fill the clearomizer by placing liquid down the side of the air hole tube. **DO NOT** place liquid directly down the air hole tube. The two pictures below indicate the correct filling method.





Do NOT fill down the centre tube. Also do not fill past the opening of the air centre tube as liquid will flow into the tube.

3. Once you have filled the clearomizer, replace the base by screwing the base back in.



Replacing Coils in your Clearomizer

The coils inside your Clearomizer are replaceable and will need to be replaced once the flavour production becomes tainted. This is usually done once a week.

1. Remove the base of the clearomizer as shown in the picture below. The coil is actually screwed into the base.



2. Unscrew the Coil from the base and replace with a new one. Replacement Coils can be purchased separately.

Using your Electronic Cigarette

Once you have charged your batteries and filled your Clearomizer, simply screw the Clearomizer onto your battery and you are ready to go.

Press the button on the battery for 1-2 seconds and then begin to slowly inhale the vapour that is produced. Be sure to inhale slowly, not draw on it like a traditional cigarette. The button on the battery must be depressed while you are inhaling and released when you are done.